



# MINI Front License Plate Holder

2013-06-12

Thank you for purchasing this ALTA product for your car! Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation. We can be reached in any of the following methods:

Email [Tech@ALTAperformance.com](mailto:Tech@ALTAperformance.com)

Instant Chat off the main page of [www.ALTAperformance.com](http://www.ALTAperformance.com)

Or simply call our tech team at 503-693-1702

## SPECIAL NOTES:

- Take great care in removing plastic OEM bumper plug. Using a flathead screwdriver and a microfiber towel (folded over at least one time) to remove is a good idea.

## Parts Included with the ALTA Front License Plate Holder:

- (1) ALTA Offset Plate holder
- (1) ALTA Tow Hook Stem
- (1) 7/16-20 SS Hex Bolt, Black Oxide
- (4) M6x10mm Button Head SS Screws
- (5) M6 SS washers
- (5) 7/16" Gr8 Flat washers, Black Oxide
- (1) M4 Hex Key
- (2) ALTA Plate Frames

## Installation of ALTA License Plate Holder:

- 1) Locate and remove front tow hook cover on front bumper. Take care in removing or damage to your paint can occur.
- 2) Install ALTA Tow Hook Stem into threaded hole using 19mm or ¾" socket and tighten to roughly 50ft-lbs. If hole looks rusty or corroded,(or you live in an area where roads are salted in winter) apply a small amount of grease to threads before installing.



- 3) Install ALTA plate holder to stem, making sure to use at least (1) flat washer between stem and holder, (1) washer and (1) washer between holder and bolt. Align plate holder to desired position and tighten bolt to roughly 30ft-lbs.
- 4) Install license plate and ALTA Plate Frame to holder, using supplied M6 bolts and washers. Hand tighten bolts only!
- 5) Ensure ALTA Plate holder and License plate do not interfere with bumper in anyway, or damage WILL occur. If plate needs to be moved away from car add washers between ALTA Tow Hook Stem and Plate Holder to move away.
- 6) After a 2-3 days of driving, recheck tightness of all hardware to ensure plate and holder have not come loose. NOTE: We recommend checking the tightness of hardware once a month to ensure plate never falls off.

Questions, Comments and Suggestions Contact: [Tech@ALTAperformance.com](mailto:Tech@ALTAperformance.com)

Visit Our Website for Instant Chat Options at <http://www.ALTAperformance.com>

Call Our Tech Team at 503-693-1702